

# Dedicated Controls

Installation and operating instructions





Original installation and operating instructions.

CONTENTS

	Page
<b>1. Symbols used in this document</b>	<b>3</b>
<b>2. Scope of these instructions</b>	<b>3</b>
<b>3. Identification</b>	<b>3</b>
3.1 Nameplate	3
3.2 Type key	4
<b>4. Installation</b>	<b>5</b>
4.1 Mechanical installation	5
4.2 Electrical installation	5
4.3 EMC and earthing	6
4.4 Schematic system overview	7
<b>5. Standard configuration</b>	<b>9</b>
5.1 CU 362	9
5.2 IO 351B	10
5.3 Float switches	11
5.4 Float switch connection	12
5.5 Analog level sensors	13
5.6 Communication	14
<b>6. Commissioning</b>	<b>15</b>
6.1 Start-up	15
6.2 Taking Dedicated Controls out of operation	15
6.3 Quick start	15
6.4 I/O settings	19
6.5 Electrical overview	22
<b>7. Maintenance</b>	<b>23</b>
7.1 CU 362	23
<b>8. Fault finding</b>	<b>24</b>
<b>9. Technical data</b>	<b>25</b>
<b>10. Electrical data</b>	<b>25</b>
<b>11. Disposal</b>	<b>25</b>

Further documentation supplied with the Dedicated Controls:

- safety instructions for Dedicated Controls
- quick guide for Dedicated Controls
- Dedicated Controls support CD-ROM
  - these installation and operating instructions
  - software description
  - additional instructions (CU 3X2, IO 351B, IO 111, CIM 2XX, etc.)
  - functional profiles
  - PC Tools.

3. Identification

3.1 Nameplate




Fig. 1 Nameplate, Dedicated Controls control cabinet

**Warning**  
 Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.

1. Symbols used in this document

**Warning**  
 If these safety instructions are not observed, it may result in personal injury.

**Caution**  
 If these safety instructions are not observed, it may result in malfunction or damage to the equipment.

**Note**  
 Notes or instructions that make the job easier and ensure safe operation.

2. Scope of these instructions

These installation and operating instructions apply to Grundfos wastewater pits with a Grundfos Dedicated Controls system. The Dedicated Controls system is designed to drain a wastewater pit with up to six pumps.

**Note**  
 The Dedicated Controls system cannot be used to fill a tank or reservoir.

The subcomponents in the control cabinet are only described in these instructions when they are important for the operation of the Dedicated Controls system.

Pos.	Description
1	Type designation
2	Model (optional)
3	Serial number
4	Mains supply
5	Power consumption
6	Fuse
7	T <sub>amb.</sub>
8	V <sub>contact max.</sub>
9	I <sub>contact max.</sub>
10	Number of fixed-speed pumps
11	I <sub>max.</sub> , relay output
12	V <sub>max.</sub> , relay output
13	Order number
14-17	Options
18	Enclosure class
19	Weight [kg]
20	CE mark
21	Country of origin

TM04 3790 5008

## 3.2 Type key

Example	DCD	318	400	3	23		DOL	-IGM
<b>Number of pumps</b>								
DC: One pump								
DCD: Two pumps								
<b>Type number</b>								
318: Control cabinet without main switch								
319: Control cabinet with main switch								
<b>Supply voltage and frequency</b>								
230: 230 V, 50/60 Hz								
400: 400 V, 50/60 Hz								
<b>Number of phases</b>								
1: Single-phase								
3: Three-phase								
<b>Maximum current per pump [A]</b>								
1: 1 - 1.5								
2: 1.5 - 2.5								
4: 2.5 - 4								
5: 1 - 5								
6: 4 - 6								
10: 6 - 10								
12: 5 - 12								
16: 10 - 16								
20: 5.5 - 20								
23: 12 - 23								
25: 20 - 25								
30: 10 - 30								
32: 25 - 32								
40: 32 - 40								
50: 40 - 50								
57: 40 - 57								
58: 50 - 58								
59: 15.5 - 59								
65: 55 - 65								
75: 65 - 75								
85: 15.5 - 85								
100: 70 - 100								
<b>Run/starting capacitor [<math>\mu</math>F] (only 12 A operating current)</b>								
[: Without capacitor								
30: Run capacitor								
30/150: 30 $\mu$ F run capacitor and 150 $\mu$ F starting capacitor								
<b>Starting method</b>								
DOL: Direct-on-line starting								
SD: Star-delta starting								
SS: Soft starter								
<b>Setup</b>								
S: Standard								
I: IO 111 (both pumps)								
G: GSM module and battery backup								
M: Mixer/flush valve								
IG: IO 111, GSM module and battery backup								
IM: IO 111 and mixer/flush valve								
GM: GSM module, battery backup and mixer/flush valve								
IGM: IO 111, GSM module, battery backup and mixer/flush valve								

## 4. Installation

Before installation, check the following:

- Do the specifications of the Dedicated Controls system correspond to the order?
- Are all visible parts intact?

### 4.1 Mechanical installation

This section describes the mechanical installation of the Dedicated Controls control cabinet and also provides general advice about how to position sensors in order to achieve stable measured values.

#### 4.1.1 Dedicated Controls

The control cabinets incorporate a CU 362 control unit connected to one or two IO 351B modules. An optional IO 111 sensor module can be connected to each pump.




Fig. 2 Example of Dedicated Controls control cabinet

The CU 362 is the "brain" of the system and must be incorporated in all systems. The units in the system can be combined in different ways according to the user's needs.

The control system controls the pumps by means of contactors and IO 351B modules. Contactors, cables and other high-voltage components should be positioned as far away as possible from the control system and the signal cables.

The control system is operated via a user-friendly control panel on the CU 362 or via a PC. Wireless remote control is available throughout the world, using a PC or mobile phone. The control system can be integrated into a user's existing SCADA system.

A specially developed PC program can be used to configure and subsequently monitor and maintain the system.

The control system can communicate in many different ways, for example with a SCADA system. Grundfos offers various fieldbus CIM communication modules that can be fitted in the CU 362. The type of protocol and line carrier being used must be taken into consideration when selecting the correct module.

#### 4.1.2 Sensors

The Dedicated Controls system requires correctly measured values in order to give an accurate indication of the pit status. It is therefore important to position and install sensors according to the manufacturer's instructions.

#### General requirements

The sensors must always be correctly sized for the range they are to measure. If the sensor is too small, it will be saturated. If it is too big, the resolution of the sensor signal will be too poor.

## 4.2 Electrical installation

The electrical connection should be carried out by an authorised person in accordance with local regulations.



#### Warning

**Before making any electrical connections, make sure that the power supply has been switched off and that it cannot be accidentally switched on.**

The following sections are intended as a supplement to the wiring diagram supplied with the Dedicated Controls control cabinet.

### 4.2.1 Terminal blocks

#### Terminal block for the mains supply

- Connect the mains supply cable.
- Connect the supply cables for each pump and the mixer, if installed. The mixer is optional.

#### Control signals

The system is controlled by various sensors, modules and relays connected to these inputs and outputs:

- AI (analog input)
- DI (digital input)
- AO (analog output)
- DO (digital output).

#### Terminal block for the IO 351B

Terminal	Input type	Terminal	Input type	Terminal	Input type
10	DI1	15	GND	18	AO4
21	GND (AO)	22	AO5	26	AO6
30	PTC1	32	PTC2	34	PTC3
35	GND (PTC)	36	PTC4	38	PTC5
40	PTC6	41	GND (PTC)	47	GND (AO)
53	24 V	55	GND	57	AI1
60	AI2	82	DO4, NO	84	DO5, NO
86	DO6, NO	88	DO7, NO	89	DO7, C
83	DO4, C	85	DO5, C	87	DO6, C
83	DO4, C	85	DO5, C	87	DO6, C

TM04 5777 3909

## Terminal block for the CU 362

Terminal	Input type	Terminal	Input type	Terminal	Input type
10	DI1	11	GND	12	DI2
13	GND	14	DI3	47	+24 V
50	+24 V	51	AI1	53	+24 V
54	AI2	57	AI3	58	GND
70	DO5, C	71	DO6, NO	72	DO6, C
73	DO6, C	74	DO7, NO	75	DO7, C

**Note** For the connection of the IO 111 module, see the installation and operating instructions for the IO 111.

In the following sections, two examples are shown:

- Two pumps with analog level sensor and safety float switches. See section 4.4.1.
- Two pumps with five float switches. Special application that requires special wiring in the control cabinet. See section 4.4.2.

## Supply voltage

Unit/ module	VAC	VDC
CU 362	1 x 100-240 VAC $\pm$ 10 %, 50/60 Hz, PE (Class 1 equipment)	Battery +12 VDC
IO 351B	1 x 100-240 VAC $\pm$ 10 %, 50/60 Hz, PE (Class 1 equipment)	-
IO 111	24 VAC $\pm$ 10 %, 50 and 60 Hz	24 VDC $\pm$ 10 %

## 4.3 EMC and earthing

If there is a risk of electrical noise, the CU 362 and the modules in the control cabinet should be earthed. This is achieved using screws on a metal back plate, which is earthed with the best possible earth connection. This must be done for personal safety and as protection against undesired electrical noise.


Signal cables must be earthed appropriately. The optimum solution is to fit a clamp to the electrically conducting back plate so that it lies over the cable and is in contact with the cable screen.

**Caution** Each pump must be connected to a separate motor protector or similar protection.

## 4.4 Schematic system overview

### 4.4.1 Two pumps with analog level sensor and safety float switches

Figure 3 shows an example of a two-pump installation with an analog level sensor (AI1, CU 362). The system has two safety float switches, i.e. for high level (DI2, CU 362) and for dry running (DI1, CU 362). A flowmeter has been installed in the discharge line. The flowmeter is both connected to an analog input (AI2, CU 362) for actual flow measurement and to a digital input (DI1, IO 351B) set up as a counter input (flowmeter).



**Fig. 3** Two pumps with analog level sensor and safety float switches

Float switch	Unit	Signal (terminal)	Description
Float switch 2	CU 362	DI2 (12), GND (13)	High level
Float switch 1		DI1 (10), GND (11)	Dry running
Sensor	Unit/module	Signal (terminal)	Description
Level sensor	CU 362	AI1 (51), +24 V (47), GND (58)	Level measurement
Flowmeter	CU 362	AI2 (54), +24 V (50), GND (58)	Actual flow measurement
	IO 351B-1	DI1 (10), GND (15)	Flowmeter (total volume)

#### 4.4.2 Two pumps with five float switches

Figure 4 shows an example of a two-pump installation controlled by five float switches. Two float switches are used as safety float switches, i.e. for high level (DI2, CU 362) and for dry running (DI1, CU 362). The last three float switches are used to start and stop the pumps, i.e. Start 1 (DI9, IO 351B), Start 2 (DI8, IO 351B) and Stop (DI3, CU 362). A pressure sensor (AI2, CU 362) has been installed in the discharge line close to the pipe junction.




Fig. 4 Two pumps with five float switches

Float switch	Unit/module	Signal (terminal)	Description
Float switch 5	CU 362	DI2 (12), GND (13)	High level
Float switch 4	IO 351B-1	DI8 (44), GND (47)	Start 2
Float switch 3	IO 351B-1	DI9 (46), GND (47)	Start 1
Float switch 2	CU 362	DI3 (14), GND (13)	Stop
Float switch 1	CU 362	DI1 (10), GND (11)	Dry running


Sensor	Unit	Signal (terminal)	Description
Pressure sensor	CU 362	AI2 (54), +24 V (50), GND (58)	Discharge pressure measurement



## 5. Standard configuration

AI	Analog input	Configuration of analog inputs. See section 6.4.1 <i>Analog inputs</i> .
DI	Digital input	Configuration of digital inputs. See section 6.4.2 <i>Digital inputs</i> .
AO	Analog output	Configuration of analog outputs. See section 6.4.3 <i>Analog outputs</i> .
DO	Digital output (relay output)	Configuration of digital outputs. See section 6.5.4 <i>Digital outputs</i> .
PTC	Positive temperature coefficient	See software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

### 5.1 CU 362


CU 362	Description	Inputs and outputs
 <p style="text-align: right; font-size: small;">TM05 3231 0912</p>	<p>The CU 362 is the "brain" of the Dedicated Controls system and is mounted in the control cabinet front.</p> <p>The CU 362 can control and monitor up to six Grundfos wastewater pumps. The pumps can drain a pit using built-in draining algorithms. The algorithms are based on a water level measured by float switches or an analog level sensor.</p>	<p>CU 362 inputs and outputs:</p> <ul style="list-style-type: none"> <li>• GENIbus communication (RS-485)</li> <li>• 3 analog inputs for connection to sensors with current (0-20 mA/4-20 mA) or voltage (0-10 V)</li> <li>• 3 digital inputs</li> <li>• 2 digital outputs, 240 VAC, 2 A</li> <li>• Connection to battery backup (UPS) (optional)</li> <li>• Ethernet connection (VNC)</li> <li>• Connection to fieldbus CIM modules (CIM = Communication Interface Module): <ul style="list-style-type: none"> <li>– CIM 200 (Modbus via RS-485)</li> <li>– CIM 250 (Modbus and SMS via GSM/GPRS)</li> <li>– CIM 270 (GRM) (GRM = Grundfos Remote Management).</li> </ul> </li> </ul>

#### Level control and safety

Signal	Terminal	Float switch	Analog sensor	Analog sensor and safety float switches	Analog sensor and mixer	Analog sensor, mixer and safety float switches
<b>Analog inputs</b>						
AI1	51	-	Level sensor	Level sensor	Level sensor	Level sensor
AI2	54	-	Flow sensor	Flow sensor	Flow sensor	Flow sensor
AI3	57	-	User-defined sensor 1	User-defined sensor 1	User-defined sensor 1	User-defined sensor 1
<b>Digital inputs</b>						
DI1	10	Float switch *	-	Dry-running float switch	-	Dry-running float switch
DI2	12	Float switch *	-	High-level float switch	-	High-level float switch
DI3	14	Float switch *	-	Overflow switch	-	Overflow switch
<b>Digital outputs</b>						
DO1 (NO)	71	High-level alarm	High-level alarm	High-level alarm	High-level alarm	High-level alarm
DO1 (NC)	72	-	-	-	-	-
DO2 (NO)	74	All alarms and warnings	All alarms and warnings	All alarms and warnings	All alarms and warnings	All alarms and warnings
DO2 (NC)	75	-	-	-	-	-

\* See section 5.3 *Float switches*.

## 5.2 IO 351B

IO 351B	Description	Inputs and outputs
	The IO 351B is a general I/O module.	IO 351B inputs and outputs:
	<p>The IO 351B communicates with the CU 362 via GENIbus.</p> <p>Via the IO 351B inputs and outputs, the CU 362 controls the pumps according to the built-in algorithms.</p>	<ul style="list-style-type: none"> <li>• GENIbus communication (RS-485)</li> <li>• 2 analog inputs for connection to sensors with current (0-20 mA/4-20 mA) or voltage (0-10 V)</li> <li>• 3 analog outputs, 0-10 V, max. 2 mA</li> <li>• 9 digital inputs</li> <li>• 7 digital outputs, 240 VAC, 2 A</li> <li>• 6 PTC inputs.</li> </ul>

TM03 2110 3705

## Level control and safety

Module	Signal	Terminal	Float switch	Analog sensor	Analog sensor and safety float switches	Analog sensor and mixer	Analog sensor, mixer and safety float switches
<b>Analog inputs</b>							
IO 351B-1	AI1	51	-	User-defined sensor 2	User-defined sensor 2	User-defined sensor 2	User-defined sensor 2
	AI2	54	-	User-defined sensor 3	User-defined sensor 3	User-defined sensor 3	User-defined sensor 3
<b>Digital inputs</b>							
IO 351B-1	DI1	10	Energy meter or flowmeter *	Energy meter or flowmeter *	Energy meter or flowmeter *	Energy meter or flowmeter *	Energy meter or flowmeter *
	DI8	44	Float switch **	-	-	-	-
	DI9	46	Float switch **	-	-	-	-
<b>Digital outputs</b>							
IO 351B-1	DO1	77	Start of pump 1	Start of pump 1	Start of pump 1	Start of pump 1	Start of pump 1
	DO2	79	Start of pump 2	Start of pump 2	Start of pump 2	Start of pump 2	Start of pump 2
	DO3	81	All alarm relays	All alarm relays	All alarm relays	All alarm relays	All alarm relays
	DO4	82	VFD 1, reverse	VFD 1, reverse	VFD 1, reverse	VFD 1, reverse	VFD 1, reverse
	DO5	84	VFD 2, reverse	VFD 2, reverse	VFD 2, reverse	VFD 2, reverse	VFD 2, reverse
	DO6	86	-	-	-	Mixer start	Mixer start
	DO7	88	User-defined alarms	User-defined alarms	User-defined alarms	User-defined alarms	User-defined alarms
<b>Analog outputs</b>							
IO 351B-1	AO1	18	-	VFD frequency, pump 1	VFD frequency, pump 1	VFD frequency, pump 1	VFD frequency, pump 1
	AO2	22	-	VFD frequency, pump 2	VFD frequency, pump 2	VFD frequency, pump 2	VFD frequency, pump 2
	AO3	26	-	-	-	-	-
<b>PTC inputs</b>							
IO 351B-1	PTC1	30	PTC, pump 1	PTC, pump 1	PTC, pump 1	PTC, pump 1	PTC, pump 1
	PTC2	32	PTC, pump 1	PTC, pump 1	PTC, pump 1	PTC, pump 1	PTC, pump 1

\* Connect either an energy meter or a flowmeter to the IO 351B-1 (DI1).

\*\* See section 5.3 *Float switches*.

### 5.3 Float switches

The CU 362 has a set of factory settings for the float switches. The functions of the float switches depend on the number of pumps and float switches installed.

If more than two pumps are installed, only two float switches can be used, and they are used as safety high-level and/or dry-running float switches.



TM02 0670 3805

Fig. 5 Float switches

#### High-level, overflow and dry-running float switches

In the pit, the high-level float switch must be physically installed above the level indicated as high level, otherwise "Conflicting levels" and "Level sensor" alarms will be triggered. See fig. 6.

The overflow switch must be physically installed at the same height as the bottom of the overflow channel. The overflow switch works in cooperation with an analog level sensor. See fig. 6.

The dry-running float switch must be physically installed below the level indicated as dry-running level, otherwise "Conflicting levels" and "Level sensor" alarms will be triggered. See fig. 6.


***The alarms "Conflicting levels" and "Level sensor" will only be triggered if an analog level sensor is installed. The analog level sensor is not shown in fig. 6.***

Note

When the high-level float switch is activated, it triggers a high-level alarm. All pumps will start at the same time, but the number of starting pumps depends on the number of pumps in each pump group.

The overflow switch activates the overflow calculation, and the analog level sensor registers the actual level in the overflow channel.

For further information about pump groups and overflow calculation, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet.



TM04 6427 0310

Fig. 6 High-level and dry-running float switches

### 5.4 Float switch connection

Install the float switches as recommended to ensure easy and correct installation. See fig. 7.




Fig. 7 Float switch installation

#### Installations with two pumps and five float switches

##### Example 1

Float switch	Unit/module	Signal (terminal)	Description
Float switch 5	CU 362	DI2 (12), GND (13)	High level
Float switch 4	IO 351B-1	DI8 (44), GND (47)	Start 2
Float switch 3	IO 351B-1	DI9 (46), GND (47)	Start 1
Float switch 2	CU 362	DI3 (14), GND (13)	Stop
Float switch 1	CU 362	DI1 (10), GND (11)	Dry running

##### Example 2

Float switch	Unit/module	Signal (terminal)	Description
Float switch 5	IO 351B-1	DI8 (44), GND (47)	Start 2
Float switch 4	IO 351B-1	DI9 (46), GND (47)	Alarm
Float switch 3	CU 362	DI3 (14), GND (13)	Start 1
Float switch 2	CU 362	DI2 (12), GND (13)	Stop
Float switch 1	CU 362	DI1 (10), GND (11)	Dry running

TM04 6428 0310

## 5.5 Analog level sensors

This section describes the most important issues concerning installation of level sensors.




Fig. 8 Analog level sensors

Level detection can be done by an analog level sensor.

We recommend the use of one of these sensors:

- pressure sensor
- ultrasonic sensor.

To ensure accurate measurements, it is important that the sensor parameters are entered correctly.

### 5.5.1 Pressure sensor

When a pressure sensor is used, special attention must be given to the sensor setting.

#### Type of control signal

- 0-20 mA
- 4-20 mA
- 0-10 V.

#### Measuring range

- Min. value [m]
- Max. value [m].

**Note**

*Float switches can be used as safety high-level, overflow and dry-running float switches.*

### 5.5.2 Ultrasonic sensor

When an ultrasonic sensor is used, special attention must be given to the sensor setting.

#### Type of control signal

- 0-20 mA
- 4-20 mA
- 0-10 V.

#### Measuring range

- Min. value [m]
- Max. value [m].

The user must state whether the measuring signal is for water depth ( $\Delta h2$ ) or distance from the top of the pump pit to the water level ( $\Delta h1$ ).

When the distance to the water level is being measured, the user must enter an "Offset". This offset gives the distance from the ultrasonic sensor to the top of the pit. Furthermore, the function "Inverted" must be selected (it is shown if an ultrasonic sensor is selected). See fig. 9.




Fig. 9 Ultrasonic sensor

TM04 6431 0310

TM04 6429 0310

## 5.6 Communication

### 5.6.1 Communication between the CU 362, IO 351B, IO 111 and CUE

The CU 362 communicates with the individual modules via GENIbus. Additional modules are connected in parallel (daisy chain). See fig. 10.




Fig. 10 GENIbus connection

### 5.6.2 GENIbus number (address)

If the Dedicated Controls has been ordered as a complete control cabinet, the GENIbus numbers have been factory-set.

If the modules have been ordered as separate components, it is the user's responsibility to set the GENIbus numbers.

Pump number	Unit/module		
	IO 351B *	IO 111 **	CUE
1	41	9 (40)	1
2		10 (41)	2

\* Three IO 351B modules can be connected to the Dedicated Controls system.

\*\* The DIP switches on the IO 111 module must be set to bus configuration if the IO 111 module is to be configured by use of a PC Tool. See installation and operating instructions for the IO 111.

## 6. Commissioning

### 6.1 Start-up

After having carried out the mechanical, hydraulic and electrical installation, proceed as follows:

1. Switch on the power supply.
2. Wait for the first display to appear.
3. The first time the CU 362 is switched on, there are two options:
  - A configuration wizard guides the user through specific settings.  
See section 6.3.1 *Configuration by wizard*.
  - The user configures the system by use of PC Tools.  
See section 6.3.2 *Configuration by PC Tool*.
4. Follow the instructions in each display.

The system is now ready for operation.

### 6.2 Taking Dedicated Controls out of operation

Switch off the main switch to take the system out of operation.

#### Warning



**The conductors in front of the main switch are still energised.**

**Lock the main switch with a padlock to ensure that it cannot be accidentally switched on.**

An individual pump is taken out of operation by switching off the power supply to the corresponding motor-protective circuit breaker, automatic circuit breaker or fuse.

It is recommended to stop one pump at a time. Stopping one pump at a time minimises pressure surges in the discharge pipe.

### 6.3 Quick start

When the system is started up for the first time, the pumps are set to "Out of operation". This ensures that the pumps do not start until the system configuration has been completed.

For information about the CU 362 operator display, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

The Dedicated Controls can be configured and put into operation in two ways:

- configuration by wizard
- configuration by use of PC Tools.

#### 6.3.1 Configuration by wizard

When the system is started up for the first time, a step-by-step configuration wizard will start. This configuration wizard helps the user to configure the system. When the configuration is completed, the system is ready for operation.



Fig. 11 Configuration by wizard


#### Help ?

Press ? to display the relevant help text. All the elements in the display have a selectable help text.

Wizard display setting	Description
Display language	Select the desired language.
Welcome	-
Date and time	Set date and time.
Units	Select units.
Installation name	Enter the installation name.
Primary settings	Select the settings required.
Modules installed	Select the modules installed.
Float switch function	Select float switch function. See section 5.4 <i>Float switch connection</i> .
Set up level sensor	Select the type of level sensor installed. See section 5.5 <i>Analog level sensors</i> .
Analog inputs	Set the analog inputs. See section 6.4.1 <i>Analog inputs</i> .
Start and stop levels	Enter start and stop levels.
Warning	-
Pump and system options	-
Digital inputs	Set the digital inputs. See section 6.5.2 <i>Digital inputs</i> .
Communication settings	Select and set up the communication. See section 6.3.3 <i>Communication</i> .
Configuration completed	The system configuration is completed, and the system is ready for operation. To set up advanced functions, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

TM04 6455 0610

## CU 362 factory settings



TM02 8305 1704

Fig. 12 Example of a two-pump installation (factory settings)

<b>Pit dimension</b>	
Pit depth	5.0 m
<b>Levels</b>	
Overflow level	4.95 m
High level	4.75 m
Alarm level	3.5 m
Start level 2	2.0 m
Start level 1	1.75 m
Stop level 1	0.5 m
Stop level 2	0.5 m
Dry-running level	0.25 m
Foam-draining level	0.15 m
Upper measurement level	1.5 m
Lower measurement level	0.5 m
Max. measurement time	3,600 sec.
Analog sensor	4-20 mA, 0-5 m



### 6.3.2 Configuration by PC Tool

For the physical connection between the PC and Dedicated Controls (CU 362), a USB cable is used.




Fig. 13 Configuration by PC Tools

Load the PC Tool WW Controls, and configure the system direct on line, or upload a prepared configuration file to the CU 362. When the system has been set up by use of PC Tools, switch on the power supply to the pump groups and protective devices of all pumps. We recommend you to set the Auto/On/Off switch to position "Auto". See fig. 14.


**Note** *If the Auto/On/Off switch is set to position "On", the Dedicated Controls system cannot be set or managed by the SCADA system.*



Fig. 14 Auto/On/Off switch

### 6.3.3 Communication

Go to the menu Settings > Communication settings. The CU 362 must have a CIM module (Communication Interface Module) fitted to be able to transfer data to the SCADA system or to a mobile phone. Various CIM modules are available, depending on the type of network. The CIM module must be fitted directly in the CU 362. See installation and operating instructions for the CU 362. For configuration of the CIM module, see the installation and operating instructions and the functional profile on the CD-ROM supplied with the module.



### 6.3.4 Selecting the CIM communication module

In this display, the CIM communication module fitted in the CU 362 must be selected. Select each of the submenus, and enter the data required in each menu. For further information, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet. Each communication module has a series of configuration submenus and special functions. The CU 362 supports these CIM modules:

- CIM 200 (Modbus RTU via RS-485)
- CIM 250 (Modbus TCP and SMS via GSM/GPRS)
- CIM 270 (GRM = Grundfos Remote Management)
- Other module (future communication modules).

**Note** *The type of communication module used can be found on the back of the CU 362.*

**Path:** Settings > Communication settings >




Fig. 15 Communication settings

**Note** *The SIM card PIN code must be set to 4321 before the CIM 270 can establish communication with a GSM network.*

Change the PIN code by inserting the SIM card into a mobile phone. Consult your mobile phone manual for further details.

### Configuration via network

When the CIM module fitted in the CU 362 has been configured, the remaining configuration can be done using the established communication line.

TM05 3267 1112

TM04 5778 3609

Display\_4.3

**6.3.5 CUE or VFD installations**

For details about the setup of the CUE and VFD, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet and the installation and operating instructions for the CUE or VFD.

**Radio modem**

If a radio modem is to be used as communication line, a CIM 200 Modbus module must be fitted in the CU 362.


The following has to be set:

- Modbus address
- Parity
- Modbus transmission speed.

See installation and operating instructions for the CIM 2XX Modbus module.

The Modbus address set in the CIM 200 Modbus module has to be set in the CU 362 as well.


1. Select "CIM 200".
2. Select the submenu "Fieldbus addresses".
3. Set the Modbus address in the line "CIM Modbus address".



**Fig. 16** Radio modem network

TM04 6490 0410

The connection between the radio modem and the CIM 200 Modbus module is established by using an RS-485 serial cable.



TM04 6992 1310

**Fig. 17** Radio modem connection via Modbus RTU

Pos.	Designation	Description
1	Common/GND	Modbus terminal Common/GND
2	D0	Modbus terminal D0 (negative data signal)
3	D1	Modbus terminal D1 (positive data signal)

## 6.4 I/O settings

This section describes how to set up inputs, outputs and alarm relays.


*The displays shown in the following sections are to be regarded as examples.*

**Note**

*The display shown may differ from the current display on the CU 362 as the display depends on the installed components and the actual configuration of the system.*

This display shows the options in menu "I/O settings".

**Path:** Settings > I/O settings >



Display\_4.4

Fig. 18 I/O settings

### 6.4.1 Analog inputs

The analog input to be set is selected in this display.

As standard, there are five analog inputs. The display shows each input so that its physical location can be quickly identified.


#### Example

The AI1 analog input on the CU 362 (designated terminal 51) is linked to the function "Level, pressure".

AI1 (CU 361) [51] and AI1 (IO351B-41) [57].

Input	Control unit/ module	Terminal
AI1	CU 362	51
AI1	IO 351B	57

**Path:** Settings > I/O settings > Analog inputs >



Display\_4.4.1

Fig. 19 Analog inputs

### Analog input, configuration

The analog input to be set is selected in this display.

Each analog input has its own display. The number of displays depends on the number of analog inputs.

#### Example

1. Select input signal type, e.g. 4-20 mA.
2. Select input value, e.g. "Level, pressure".
3. Set sensor measuring range (minimum and maximum limits), e.g. 0.0 to 5.0 m.


**Note**

*If an analog input is disabled, the display will only show the upper part, i.e. the input setting.*

If the input is enabled, "Measured input value" is shown.

A function can be linked to an analog input in another display. The CU 362 will return to the analog input setting display.

**Path:** Settings > I/O settings > Analog inputs > Analog inputs >




Display\_4.4.1.1

Fig. 20 Analog inputs

### Analog inputs, input value

The input value for the selected analog input is set in this display.

**Path:** Settings > I/O settings > Analog inputs > Analog inputs > Analog inputs and measured value >



Display\_4.4.1.1.1

Fig. 21 Analog inputs and measured value

### 6.4.2 Digital inputs


The digital input to be set is selected in this display. As standard, there are 12 digital inputs. The display shows each input so that its physical location can be quickly identified.

#### Example

The DI2 digital input on the IO 351B (designated terminal 12) is linked to the function "Contactor feedback, pump 1", and the contactor type is normally open. DI1 (CU 361) [10] and DI2 (IO351B-41) [12].

Input	Control unit/ module	Terminal
DI1	CU 362	10
DI2	IO 351B	12

**Path:** Settings > I/O settings > Digital inputs >




Display\_4.4.2

Fig. 22 Digital inputs

#### Digital inputs and functions

The signal input logic and the digital input function are set in this display.

**Path:** Settings > I/O settings > Digital inputs > Digital inputs and functions >



Display\_4.4.2.1

Fig. 23 Digital inputs and functions

### 6.4.3 Analog outputs


The analog output to be set is selected in this display. As standard, there are three analog outputs. The display shows each output so that its physical location can be quickly identified.

#### Example

The AO1 analog output on the IO 351B (designated terminal 18) is linked to the function "VFD frequency, pump 1". AO1 (IO351B-41) [18].

Input	Module	Terminal
AO1	IO 351B	18

**Path:** Settings > I/O settings > Analog outputs >



Display\_4.4.3

Fig. 24 Analog outputs

### 6.4.4 Digital outputs

The digital output to be set is selected in this display.

As standard, there are nine digital outputs. The display shows each digital output so that its physical location can be quickly identified.

#### Example

The DO1 digital output on the CU 362 (designated terminal 71) is linked to "High-level alarm".

DO1 (CU 361) [71] and DO1 (IO351B-41) [77].

Output	Control unit/ module	Terminal
DO1	CU 362	71
DO1	IO 351B	77

Path: Settings > I/O settings > Digital outputs >




Fig. 25 Digital outputs

### Digital outputs, output value

The output value for the selected digital output is set in this display.

#### Example

The DO1 digital output on the CU 362 (designated terminal 71) is linked to "High-level alarm".

Path: Settings > I/O settings > Digital outputs > Function of digital outputs >




Fig. 26 Function of digital outputs

For further information, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

### 6.4.5 Counter inputs

The counter input to be set is selected in this display.

A counter input can connect to a flowmeter or energy meter.

As standard, there are two counter inputs. Each counter can be set via a submenu.

Path: Settings > I/O settings > Counter inputs >




Fig. 27 Counter inputs

### Counter inputs, configuration

The selected counter input is set in this display.

1. Identify the digital input connected to a flowmeter in the system.
2. Select the digital input the flowmeter is connected to, unit and scaling.

**Note**

*The IO 351B pulse input has a maximum frequency of 12 Hz.*

For further information, see software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

Path: Settings > I/O settings > Counter inputs > Flowmeter >




Fig. 28 Flowmeter

Display\_4.4.5

Display\_4.4.4


Display\_4.4.4.1

Display\_4.4.5.1

## 6.5 Electrical overview

This display shows an overview of the various inputs and outputs. The submenus in this display are described in the following sections.

**Path:** Status > Electrical overview >



Display\_1-10

Fig. 29 Electrical overview

### 6.5.1 Analog inputs

This display shows the status of the individual analog inputs.

#### Example

Analog input AI1 (CU 361) [51]:

The AI1 analog input on the CU 362 (designated terminal 51) is set up as a current input.

The measured value of 14.9 mA corresponds to a level and a pressure of 3.40 m.

**Path:** Status > Electrical overview > Analog inputs >

Analog inputs and measured value	
AI1 (CU 362) [51] [Level, pressure]	15.4 mA 3.55m
AI2 (CU 362) [54] [Flow rate]	4.8 mA 1.0 m³/h
AI3 (CU 362) [57] [Not used]	-- --
AI1 (IO 351B-41) [57] [Not used]	-- --
AI2 (IO 351B-41) [60] [Not used]	-- --

Display\_1-10.1

Fig. 30 Analog inputs

**Note**

*If an ultrasonic sensor is used, this display only shows the "raw" value without offset and not inverted.*

### 6.5.2 Digital inputs

This display shows the status of the individual digital inputs.

#### Example

Digital input DI2 (IO351B-41) [12]:

The DI2 digital input on the IO 351B (designated terminal 12) is linked to the function "Contactor feedback, pump 1", and the contact is closed.

**Path:** Status > Electrical overview > Digital inputs >

Digital inputs and functions	
DI1 (CU 362) [10] (Not used)	Not active
DI2 (CU 362) [12] (Not used)	Not active
DI3 (CU 362) [14] (Not used)	Not active
DI1 (IO 351B-41) [10] (Not used)	Not active
DI2 (IO 351B-41) [12] (Contactor feedback, pump 1)	Active
DI3 (IO 351B-41) [14] (Contactor feedback, pump 2)	Not active

Display\_1-10.2

Fig. 31 Digital inputs

### 6.5.3 Analog outputs

This display shows the status of the individual analog outputs.

#### Example

Analog output AO1 (IO351B-41) [18]:

The AO1 analog output on the IO 351B (designated terminal 18) is linked to the function "VFD frequency, pump 1", and the analog output signal is 10.0 V equal to 50.0 Hz.

**Path:** Status > Electrical overview > Analog outputs >

Analog outputs and functions	
AO1 (IO 351B-41) [18] (VFD frequency, pump 1)	10.0V 50.0Hz
AO2 (IO 351B-41) [22] (VFD frequency, pump 2)	0.0V 0.0Hz
AO3 (IO 351B-41) [26] (Not used)	0.0V --

Display\_1-10.3

Fig. 32 Analog outputs

### 6.5.4 Digital outputs

This display shows the status of the individual digital outputs.

#### Example

Digital output DO1 (CU 361) [71]:

The DO1 digital output on the CU 362 (designated terminal 71) is linked to "High-level alarm", and the relay is active.

**Path:** Status > Electrical overview > Digital outputs >

Status	Drift	Alarm	Settings
1.10.4 - Digital outputs			
Digital outputs and functions			
DO1 (CU 362) [71] (High-level alarm)			Active
DO2 (CU 362) [74] (All alarms and warnings)			Active
DO1 (IO 351B-41) [77] (Start, pump 1)			Active
DO2 (IO 351B-41) [79] (Start, pump 2)			Not active
DO3 (IO 351B-41) [81] (All alarms)			Active
DO4 (IO 351B-41) [82] (Urgent alarms)			Active
GRUNDFOS 2012-07-10 15:44			

Display\_1.10.4

Fig. 33 Digital outputs

### 6.5.5 User-defined functions

This display shows all functions (up to eight) defined by the user. Each user-defined function is shown with two sources and the selected functions. In the top right corner of each user-defined function, the actual status is shown (Active/Not active).

See software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

#### Example

"User-def. function 1" has been activated by the 1st source, which has been set to "Constantly high". The 2nd source has also been set to "Constantly high".

"User-def. function 1" is linked to a digital output.

See software description on the CD-ROM supplied with the Dedicated Controls control cabinet.

**Path:** Status > Electrical overview > User-defined functions >

Status	Operation	Alarm	Settings
1.10.5 - User-defined functions			
User-defined functions and inputs			
User-defined function 1 (Constantly high)			Active
(Constantly high)			Active
My function (All pumps running)			Not active
(Timer function)			Not active
Leakage detected (AI2 (IO 351B-41) [60])			Active
(Constantly high)			Active
Run ventilation (Constantly high)			Active
(DI1 (CU 362) [10])			Not active
User-defined function 5			--
GRUNDFOS 2012-07-10 15:44			

Display\_1.10.5

Fig. 34 User-defined functions

## 7. Maintenance



#### Warning

*Before starting work on the pumps, make sure that the power supply has been switched off.*

*Lock the main switch with a padlock to ensure that it cannot be accidentally switched on.*

### 7.1 CU 362

The CU 362 is maintenance-free. It should be cleaned with a dry or wet cloth. Protect it from direct sunlight. Furthermore, the CU 362 temperature must not be outside the ambient temperature range. See section 9. *Technical data*.

## 8. Fault finding



### Warning

Before making any connections in pumps, terminal boxes or control cabinet, make sure that the power supply has been switched off for at least 5 minutes and that it cannot be accidentally switched on.

Fault	Cause	Remedy
1. Pumps do not run when started.	a) CU 362 fault.	• Reset alarms, or replace the CU 362.
	b) Power supply disconnected.	• Switch on the power supply. • Replace fuse. • Replace the main switch.
	c) Main switch cut out.	• Cut in the main switch.
	d) Main switch defective.	• Replace the main switch.
	e) Motor protection tripped.	• Check the setting. • Motor defective. • Open thermistor. • Phase failure. • Contact Grundfos.
	f) Motor defective.	• Repair or replace the motor.
	g) Sensor fault.	• Check sensor configuration. • Replace the sensor.
	h) Cable defective.	• Repair or replace the cable.
	i) No water in pump pit.	• Wait until the level control activates a pump.
	j) Level control fault.	• Check level control configuration. • Replace the sensor/float switch.
	k) External on/off switch switched off.	• Switch on the on/off switch.
2. Pumps start, but stop immediately.	a) Dry running or no inlet pressure.	• Wait until the level control activates a pump.
	b) Motor protection tripped.	• Check the setting. • Motor defective.
	c) Level control fault.	• Check level control configuration. • Replace the sensor/float switch.
3. Pump performance unstable.	a) Suction port blocked by impurities.	• Clean the pump.
	b) Suction pipe or pumps partially blocked by impurities.	• Clean the suction pipe, strainer or pumps.
	c) Pumps suck air.	• Incorrect positioning of pump relative to level control (dry running).
	d) Valves closed.	• Open the valves.
4. Pumps are running, but deliver no water.	a) Valves closed.	• Open the valves.
	b) Suction pipe or pumps blocked by impurities.	• Clean the suction pipe or pumps.
	c) Non-return valve blocked in closed position.	• Clean the non-return valve. The non-valve must be able to move freely.
5. Pumps start and stop frequently.	a) Incorrect distance between start and stop levels.	• Set start and stop levels correctly.



## 9. Technical data

### Altitude above sea level

Maximum 2,000 m.

### Ambient temperature

- During operation: 0 °C to +50 °C  
(must not be exposed to direct sunlight).  
At temperatures below 0 °C, the display may react slowly.
- In stock: -20 °C to +60 °C.
- During transportation: -20 °C to +60 °C.

### Relative air humidity

5 to 95 %.

### Enclosure class

IP54.

## 10. Electrical data

### Supply voltage

See nameplate on Dedicated Controls.

### Backup fuse

See the wiring diagram supplied with the Dedicated Controls system.

### Digital inputs

Open-contact voltage	24 VDC
Closed-contact current	5 mA, DC
Frequency range	0-4 Hz

**Note** All digital inputs are supplied with SELV voltage (Safety Extra-Low Voltage).

### Analog inputs

Input current and voltage	0-20 mA 4-20 mA 0-10 V
Tolerance	± 3.3 of full scale
Repetitive accuracy	± 1 % of full scale
Input resistance, current	< 250 Ω
Input resistance, voltage, CU 362	> 50 kΩ ± 10 %
Input resistance, voltage, IO 351B	> 50 kΩ ± 10 %
Sensor supply	24 V, 30 mA, short-circuit-protected

**Note** All analog inputs are supplied with SELV voltage (Safety Extra-Low Voltage).

### Digital outputs (relay outputs)

Maximum contact load	240 VAC, 2 A
Minimum contact load	5 VDC, 10 mA

All digital outputs are potential-free relay contacts.

*Some outputs have a common C terminal.*

**Note** For further information, see the wiring diagram supplied with the Dedicated Controls system.

### Inputs for PTC sensor/thermal switch

For PTC sensors to DIN 44082. A thermal switch can also be connected.

Open-circuit voltage	12 VDC ± 15 %
Closed-circuit current	2.6 mA, DC

**Note** Inputs for PTC sensors are electrically separated from the other inputs and outputs of the Dedicated Controls system.

## 11. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Subject to alterations.



**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana, ramal Campana Centro Industrial Garin - Esq. Haendel y Mozart  
AR-1619 Garin Pcia. de Buenos Aires  
Pcia. de Buenos Aires  
Phone: +54-3327 414 444  
Telefax: +54-3327 45 3190

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomssesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в Минске  
220123, Минск,  
ул. В. Хоружей, 22, оф. 1105  
Тел.: +(37517) 233 97 65,  
Факс: +(37517) 233 97 69  
E-mail: grundfos\_minsk@mail.ru

**Bosnia/Herzegovina**

GRUNDFOS Sarajevo  
Trg Heroja 16,  
BiH-71000 Sarajevo  
Phone: +387 33 713 290  
Telefax: +387 33 659 079  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
50/F Maxdo Center No. 8 Xingyi Rd.  
Hongqiao development Zone  
Shanghai 200336  
PRC  
Phone: +86 21 612 252 22  
Telefax: +86 21 612 253 33

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Cebini 37, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.grundfos.hr

**Czech Republic**

GRUNDFOS s.r.o.  
Čajkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111  
Telefax: +420-585-716 299

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Mestarintie 11  
FIN-01730 Vantaa  
Phone: +358-3066 5650  
Telefax: +358-3066 56550

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
e-mail: infoservice@grundfos.de  
Service in Deutschland:  
e-mail: kundendienst@grundfos.de

**HILGE GmbH & Co. KG**

Hilgestrasse 37-47  
55292 Bodenheim/Rhein  
Germany  
Tel.: +49 6135 75-0  
Telefax: +49 6135 1737  
e-mail: hilge@hilge.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Park u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private Limited  
118 Old Mahaballipuram Road  
Thoraiakkam  
Chennai 600 096  
Phone: +91-44 2496 6800

**Indonesia**

PT GRUNDFOS Pompa  
Jl. Rawa Sumur III, Blok III / CC-1  
Kawasan Industri, Pulogadung  
Jakarta 13930  
Phone: +62-21-460 6909  
Telefax: +62-21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
Gotanda Metalion Bldg., 5F,  
5-21-15, Higashi-gotanda  
Shiagawa-ku, Tokyo  
141-0022 Japan  
Phone: +81 35 448 1391  
Telefax: +81 35 448 9619

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Stramsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос  
Россия, 109544 Москва, ул. Школьная 39  
Тел. (+7) 495 737 30 00, 564 88 00  
Факс (+7) 495 737 75 36, 564 88 11  
E-mail grundfos.moscow@grundfos.com

**Serbia**

GRUNDFOS Predstavništvo Beograd  
Dr. Milutina Ivkovića 2a/29  
YU-11000 Beograd  
Phone: +381 11 26 47 877 / 11 26 47 496  
Telefax: +381 11 26 48 340

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovenia**

GRUNDFOS d.o.o.  
Šlandrova 8b, SI-1231 Ljubljana-Črnuče  
Phone: +386 1 568 0610  
Telefax: +386 1 568 0619  
E-mail: slovenia@grundfos.si

**South Africa**

GRUNDFOS (PTY) LTD  
Corner Mountjoy and George Allen Roads  
Wilbart Ext. 2  
Bedfordview 2008  
Phone: (+27) 11 579 4800  
Fax: (+27) 11 455 6066  
E-mail: lsmart@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentesilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
Box 333 (Lunnagårdsgatan 6)  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31 331 94 60

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-1-806 8111  
Telefax: +41-1-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloom Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

ТОВ ГРУНДФОС УКРАЇНА  
01010 Київ, Вул. Московська 8б,  
Тел.: (+38 044) 390 40 50  
Факс.: (+38 044) 390 40 59  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971 4 8815 166  
Telefax: +971 4 8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 8TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
17100 West 118th Terrace  
Olathe, Kansas 66061  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Представительство ГРУНДФОС в Ташкенте  
700000 Ташкент ул.Усмана Носира 1-й тулик 5  
Телефон: (3712) 55-68-15  
Факс: (3712) 53-36-35

Revised 27.04.2012

<b>97726036</b> 0812
----------------------

ECM: 1096949
--------------

The name Grundfos, the Grundfos logo, and the payoff Be-Think-Innovate are registered trademarks owned by Grundfos Management A/S or Grundfos A/S, Denmark. All rights reserved worldwide.